

# AUTOMATIC CREW SERVE DISPENSER

## How to Replace a Cup Holder



**Tools Needed:** Phillips-head screwdriver

### Step 1

#### Remove the carousel:

a. Loosen thumbscrews on carousel lid.



b. Lift the cover upwards slightly.



c. Disconnect the ethernet cable from the cover.



d. Remove the cover completely by lifting it upwards.




## AUTOMATIC CREW SERVE DISPENSER

### How to Replace a Cup Holder

#### Step 2

#### Remove cup parts:


- Flip over the carousel assembly.
- Identify cup to replace.
- Remove two screws going into cup holder.
- Remove metal bracket for that cup holder from belt.



#### Step 3

#### Remove cup holder:

- Lift up carousel slightly, so you can push the cup holder down.
- Slide cup holder off the belt.



#### Step 4

#### Put the new cup holder on:

- Reverse steps to replace it.
- Only hand-tighten screws.
- Put the carousel back onto the ACSD.

