



AUTOMATIC CREW SERVE DISPENSER

Cup Purge Feature


How to Empty the Cup Dispenser.



Step 1

Enter the service menu


by pressing the gear icon on the top left of the main UI.



Step 2

Enter the passcode


Passcode 9876.



Step 3

From the Navigation menu

on the top left, select *Cup Purge*.



Step 4

In the Cup Purge screen,

select the cup tube you'd like to evacuate.
The unit will continuously dispense cups.

Note: To dispense more than 3 cups, toggle the Automatic Carousel Advance option to Enable. This will advance the carousel with each cup dispense to make it easier to retrieve the evacuated cups.



Continued on back...



AUTOMATIC CREW SERVE DISPENSER


Cup Purge Feature

How to Empty the Cup Dispenser.



Step 5

To stop cup dispensing,
select the cup tube again.



Step 6

Exit the service menu
to return to normal operation.

