

QUEST CARE AND CLEANING

DAILY: CLEANING

- Remove the nozzles by rotating a 1/4 turn and pulling straight down. The static mixer can now be removed. Wash using mild dish soap.

- To reinstall the nozzle, be sure the static mixer is in place. Push the nozzle up until it stops. Rotate it 1/4 turn to lock. Give it a slight pull to be sure it is secured. The nozzle is locked in when the wings as point out in the picture are parallel to the front panel.

IMPORTANT: Do not wash the nozzles and mixers or any plastic parts in a dishwasher. Dishwashing can distort and discolor these plastic parts and can cause damage to the nozzle o-ring. Only use warm water and a mild detergent.

- Clean the external cabinet and splash areas including the door gasket. Remove and clean the drip tray and cup rest using mild dish soap.

IMPORTANT: Condensation that forms in the cabinet drains into the drip tray. Leaving the tray off or not having it pushed completely back in place will cause the cabinet drain tube to misalign. This results in water dripping on to the counter from under the front left side of the dispenser.



WEEKLY : SANITIZING

- Prepare two 2 oz. (59 ml) packets of Stera-Sheen Green Label sanitizing solution (or similar brand) by dissolving each packet in 1 gallon (3.8L) of potable water to ensure 200 ppm of available chlorine.

IMPORTANT: Only use Potable water at 80F-100F temperature. Water above this range will breakdown the chlorine solution and minimize sanitation.

- Remove the juice concentrate containers and place them in separate refrigerated compartment.
- Fill a clean empty concentrate container with one quart of extremely hot tap water, approximately 140°F (60°C) and place the container into the unit. Dispense all of the hot water into a large container. Repeat for all the remaining dispense valves.
- Remove the mixing chambers, nozzles, and static mixers. Rinse in hot water to remove excess pulp and concentrate.
- Place the mixing chambers, nozzles, and static mixers in a separate container of sanitizing solution and agitate vigorously. Allow the parts to soak for two minutes.

IMPORTANT: Do leave the nozzles or mixers in the sanitizing solution for longer than 5 minutes. Prolonged exposure will cause damage to the plastic.

- Rinse static mixer, nozzles and mixing chambers thoroughly with fresh tap water.
- Reinstall the static mixer, nozzles and mixing chambers.

- If concentrate has been spilled inside the dispenser and it is required to remove the inside tray, be sure that the grommets are re-affixed over the neck of the adaptor not just resting on top after tray is replaced.

- Replace juice concentrates and flush the unit by dispensing and discarding approximately 8 oz from each valve.

