

DURAFLEX/ENDURO

LID AND STRAW HOLDER

Installation Instructions

NOTE: The kit may be installed on either side of the unit (right side shown).

1. Locate the 2 bottom screws, towards the front of the unit, and loosen but do not remove.
2. Align and insert slots in kit panel behind the screws and retighten. Make sure the panel is vertical and aligned with the sides of the unit.

NOTE: The following point will not apply to the DF/ED 250 units.

- If the Icemaker adapter is to be installed or already is installed on the top of the unit, the top 2 install holes in the panel will not be utilized.
3. Carefully fasten panel to the side of the unit, using self-tapping screws, start with the middle holes and work up.
 4. Attach the lid and straw holders to panel, as shown.

