

INSTALLATION INSTRUCTIONS

MILLENNIUM PUSH LEVER KIT

1. Disconnect all Syrup and water feeds to the machine and drain all stations, then unplug the machine.

2. Remove merchandiser, fluorescent light assembly and merchandiser frame.




3. Remove flavor strip panel and valve block enclosure.



4. Remove nozzles and static mixers. Disconnect all push button switches and all water solenoids. Disconnect all water and syrup lines from the valves.





5. Remove the valve block support with the valves.




6. Remove all valves from the valve block support.



7. Remove the strain reliefs from the valve block support.




8. Remove the old valve block bracket. Attach the new bracket assembly with the lever. Repeat for each valve. Discard the old valve block support, valve block enclosure and valve bracket.





9. Attach the new valve assemblies to the new valve block support. Insert the wire strain reliefs in the new valve support bracket.



10. Insert the wires through the strain reliefs and attach the new valve support bracket with the new valve assemblies to the machine.



11. Reconnect all solenoid wires. Connect wires that used to be connected to the push button switches to the micro-switches on the valve assemblies. The wires for the solenoids and switches are numbered. Valve 1 is on the far left-hand side.



12. Reattach all water and syrup lines. Reinstall the static mixers and nozzles. Attach the new valve block enclosure. Reassemble the light assembly and merchandiser.

