DMS Installation Instructions – IDC PRO (pre June 2018 models)

- 1. Download the provided "device-config.tar.gz" file and copy it onto the USB drive.
- Download the latest IDC Pro software (1.9.5 as of September 2018) from <u>http://newproducts-cornelius.com/software-update/</u> and copy it onto the USB drive.
- 3. Plug in the USB stick into any USB port on the back of IDC Pro door (temporarily unplug one of the USB cables).





4. Enter the Service UI by touching four corners of the screen and entering "3333" as password.







2

5. Select Update Software.







3

6. Press Launch Software Updater, then Update Software.









7. Choose latest software version downloaded earlier to your USB drive (1.9.5 as of September 2018) and press **Install Software**.

Note:

After successful update, the machine will restart.







8. Re-enter Service UI and press WiFi Setup.







9. Locate the name of your WiFi network. Check "Automatically connect to this network". Click **Connect**.



Tap and drag this button to move the keyboard if needed.





10. If the WiFi network requires a password, you will be prompted to enter it. Click the **Key** text field at the bottom and enter the password using the on screen keyboard. Then click **OK** at the bottom.



- Ensure the connection was successful by observing bottom-left corner of the Wicd Network Manager screen. "Connected" message along with the *IP* address should be displayed as shown below.
- 12. Close the Wicd Manager and on-screen keyboard (click on X in upper-right corners).

13. Select IoT Admin.

10

14. Press Load and choose the appropriate folder from your USB drive.

15. Select and load "device-config.tar.gz" file.

loT Admin					
Load IoT Configuration Files					
	Load Backup				
Network Configuration					
10	00:00:00:00:00:00				
eth0	08:60:6e:f8:c8:a2				
ethl	08:60:6e:f8:16:92				
wlan0	ac:fd:ce:76:f0:20				
IP Addr	IP Addresses:				
10	127.0.0.1				
eth0	206.8.87.30				

16. Click **Back** when done.

loT Admin					
Load IoT Configuration Files					
		Load Ba	ickup		
Network Configuration					
	lo eth0 eth1 wlan0 IP Addr lo	00:00:00:00:00:00 08:60:6e:f8:c8:a2 08:60:6e:f8:16:92 ac:fd:ce:76:f0:20 esses: 127.0.0.1			
WELLINDON Natural Satur	eth0	206.8.87.30	Network Test		
WIFT Hidden Network Setup					
OFF IDC Pro Controls WIFI	SSID		KEY	Te	est Save
Remote Content					
ON Media Feed	Test Feed	2-0dd8-42f6-b89e-2	aa27285a4cb.xml	Keyboard	Load From USB
					Back

(Grnelius)

17. Press System Settings and ensure that the <u>clock</u> and <u>time zone</u> are set properly.
18. Reboot the machine by clicking Shutdown and selecting Reboot option.
19. Unplug your USB drive and plug the USB cable back in.

13

Appendix

 Units built the 26th week of 2018 and later can skip steps 1 and 13-16. To check if a unit can skip these steps, find the 12-digit serial number, and note the 4th, 5th, 6th, and 7th digits. These digits represent the year and week the unit was manufactured. For example, the serial number 62A1830RP123 was manufactured the 30th week of 2018 so it can skip the listed steps.

