

# INSTALLATION INSTRUCTIONS

## ED/DF 2XX Agitator Gear Motor Capacitor

### SAFETY INSTRUCTIONS

#### SAFETY

 **WARNING:**

Before starting installation, read and understand all safety label and warnings on the machine. Also review and understand all safety instructions in the owners, installation and service manuals.

**Failure to comply could result in serious injury, death or damage to the equipment.**

#### QUALIFIED SERVICE PERSONNEL

 **WARNING:**

Only trained and certified electrical, plumbing and refrigeration technicians should service this unit.

**All wiring and plumbing must conform to national and local codes. Failure to comply could result in serious injury, death or equipment damage.**

#### SAFETY PRECAUTIONS

This unit has been specifically designed to provide protection against personal injury. To ensure continued protection observe the following:

 **WARNING:**

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

**Failure to comply could result in serious injury, death or damage to the equipment.**

 **CAUTION:**

Always be sure to keep area around the unit clean and free of clutter.

**Failure to keep this area clean may result in injury or equipment damage.**

## INSTALLATION INSTRUCTIONS

**IMPORTANT:** The motor capacitor must be re-installed on the agitator gear motor prior to installing the agitator gear motor on the dispenser.

1. Unpack the agitator gear motor and capacitor. (620048092)



Figure 1.

2. Remove the capacitor mounting screw.



Figure 2.

3. Assemble capacitor with mounting screw, as shown



Figure 3.

4. Attach the brown leads from the agitator gear motor to the capacitor. It does not matter which brown wire goes to which capacitor terminal.



Figure 4.